

## **Metric to Imperial Conversion Chart**

mm	Imperial
3.2	1/8"
4.8	3/16"
6.4	1/4"
7.9	5/16"
9.5	3/8"
11.1	7/16"
12.7	1/2"
14.3	9/16"
15.9	5/8"
17.4	11/16"
19.1	3/4"
20.6	13/16"
22.2	7/8"
23.8	15/16"
25.4	1"
28.6	1 1/8"
31.8	1 1/4"
34.9	1 3/8"
38.1	1 1/2"
41.3	1 5/8"
44.5	1 3/4"
47.6	1 7/8"
50.8	2"
54	2 1/8"

mm	Imperial
57.2	2 1/4"
60.3	2 3/8"
63.5	2 1/2"
66.7	2 5/8"
69.9	2 3/4"
73	2 7/8"
76.2	3"
82.6	3 1/4"
88.9	3 1/2"
95.3	3 3/4"
101.6	4"
107.9	4 1/4"
114.3	4 1/2"
127	5"
133.4	5 1/4"
139.7	5 1/2"
152.4	6"
177.8	7"
190.5	7 1/2"
203.2	8"
228.6	9"
254	10"
279.4	11"
304.8	12"

For other sizes, you can quickly and easily work out the Conversions for yourself, using the following simple formulae;

To convert <b>Centimetres to Inches</b>	multiply by; <b>0.3937</b>	mm to Inches; multiply by; 0.03937
To convert Metres to Feet	multiply by; 3.281	Metres to Inches; multiply by; 39.37

Whether you are comparing screw or bolt sizes, or you simply need to find the Imperial equivalent for any other metric sized unit, we hope you will find this quick reference chart easy to use and helpful.